


# GLASS BASIN INSTALLATION



Glass basins are supplied with a chrome seating ring, this MUST be used .




Seating kit

Contains O-ring, spacer seal and chrome seating ring



Completed seating ring

O-ring goes on bottom of ring  
Spacer seal goes on top of ring



Basin Installed

Place completed seating ring over waste hole in benchtop.  
Place basin on the seating ring and level.

Waste goes through basin and benchtop and is attached by tightening the waste.

32mm Plug and waste required: **Benchtop needs 45mm hole**